



Angelhood

上海安继行餐饮设备有限公司

上海市虹梅南路4999号8号楼 P.C. 201109 Tel: (86 21)51691855 Fax: (86 21)51687575

## 使用说明书

### 一、产品用途:

本产品广泛用于设定午休时间、学习时间、美容时间、煲汤时间、晒版时间……等等。

### 二、产品功能:

本产品精确度以秒为单位计算,最大容量为99分59秒。

### 三、使用方法:

- 1、按 MIN 键设置“分”所指位置。
- 2、按 SEC 键设置“秒”所指位置。
- 3、按 START/STOP 键开始或停止倒计时。
- 4、当设定时间倒数为“零”秒时发生警报。
- 5、按任意键停止警报。
- 6、同时按 MIN 和 SEC 键显示归零重新设定。(小)  
按 RESET 键显示归零重新设定。(大)

### 四、电池使换:

- 1、当计时器显示不清楚时要更换电池。
- 2、使用钮扣 G13 型电池。(小)  
使用 7 号 AAA 型电池。(大)
- 3、滑开电池门,取出旧电池,分清新电池正负极放进去,



电子倒计时器(大)

## INSTRUCTIONS

### One、production use

This production can enactment noon break time、study time、hairdressing time、stew time、sun edition time……and so on.

### Two、production function

This production is be read display maximum countdown capacity of 99 minutes 59 seconds.

### Three、use means

- 1、 Press MIN button to set desired minutes.
- 2、 Press SEC button to set desired seconds.
- 3、 Press START/STOP button once to start timer.
- 4、 Be enactment time to count down is “ZERO” second hour occurrence alert.
- 5、 Press RESET button to stop alarm.
- 6、 Press MIN to show with SEC key to return the zero to reset at the same time.(small)  
Press RESET to return to the zero.(big)

### Four、batteries use and barter

- 1、 Replace battery whenever reading becomes dim &difficult to read.
- 2、 Usage button G13 type battery.(small)  
Usage size 7 AAA type battery.(big)
- 3、 Open the battery door ,and take out the old battery ,and peg out the new battery plus or minus very put into ,and press back the home position the battery door.



电子倒计时器(小)