





BI-2000 SPARE PARTS LIST



1, SE-FAN-CB-20A
2, SENSOR
3, SE-LOGIC-CB-20A
4, COIL

5, SE-PCB-CB-20A
6, KNOB
7, SE-FOIL-CB-20A
8, SE-CTRL-CB-20A